

1. DOWNLOAD THE WAHOO APP FOR OPTIMIZED PERFORMANCE AND ESSENTIAL FIRMWARE UPDATES
Ensure Bluetooth is on.





GO TO WWW.WAHOOFITNESS.COM
TO VIEW OTHER POPULAR COMPATIBLE
TRAINING APPS.

2. PUT ON THE TICKR
Dampen the electrodes on the strap for easier pairing. Then snap the TICKR into the strap, fit strap around your chest and snap the other side of the TICKR into place. Adjust for snug fit.




3. PAIR SENSOR
Open app to Sensors page and select "Add New Sensor."




4. SAVE SENSOR

1. TURN ON THE ELEMNT AND GO TO MENU
Press the top left button to get to the menu



2. SELECT ADD SENSOR



3. ACTIVATE THE TICKR AND HOLD IT NEXT TO THE ELEMNT



4. SAVE SENSOR



RED FLASH: heartbeat is detected

BLUE SLOW BLINK (about once every second): awake and searching
TRIPLE FLASH: occurs the instant a connection is made
FAST BLINK (about twice every second): paired to a device

NOTE: LEDs turn off after 30 seconds



ENJOY YOUR WORKOUT!

FOR MORE INFORMATION GO TO
WAHOOFITNESS.COM/INSTRUCTIONS

ZA VEČ INFORMACIJ OBIŠČITE WAHOOFITNESS.COM/INSTRUCTIONS / INFORMACIJE

Prilagodite nastavitve vadbe // Prilagodite LED diode in zvoke // Dodajte pot v svojo napravo // Pridobite navodila po korakih // Prilagodite funkcijo // Strava Live Segments // Pridobite načrtovane vadbe v svoji napravi // in še več!

Izjava o skladnosti



APLIKACIJA ZA SEZNANJANJE NAPRAV

1. PRENEŠITE APLIKACIJO WAHOO ZA OPTIMIZACIJO DELOVANJA IN POTREBNE POSODOBITVE NAMEŠČENE PROGRAMSKE OPREME. Prepričajte se, da je omogočena funkcija Bluetooth.
2. NAMEŠČITE NAPRAVO TICKR. Navlažite elektrode na traku, da bo seznanjanje lažje. Nato TICKR pritrdite na trak, ovijte trak okoli prsnega koša in pripnete drugo stran traku. TICKR pritrdite na svoje mesto. Nastavite tako da se dobro prilaga.
3. ZDRUŽITE NAPRAVO TICKR. Odprite aplikacijo na strani Senzorji in izberite Pair Sensor.
4. SHRANITE SENZOR.

POVEZOVANJE NAPRAV ELEMNT

1. VKLOPITE ELEMENT IN DOSTOPITE DO MENIJA. Za vstop v meni pritisnite gumb v zgornjem levem kotu.
2. IZBERITE DODAJ SENZOR.
3. AKTIVIRAJTE NAPRAVO TICKR IN JO PRIDRŽITE V BLIŽINI ELEMENTA
4. SHRANITE SENZOR.

LED INDIKATORJI

RDEČA - utripa: vsakič, ko je zaznan srčni utrip. MODRA - UTRIPA POČASI (približno enkrat na sekundo): aktivno stanje in ni seznanjeno. TRJE utripa: pojavi se ob trenutku povezovanja. HITRO UTRIPANJE (približno dvakrat na sekundo): seznanjeno z napravo. Opomba. Svetleče diode se po 30 sekundah izklopijo.